

# Filling level sensor

Original operating manual

**Series**  
**UFM**  
**UFM Flex**  
**UFM C2**



Version BA-2017.06.30 EN  
Print-No. 300 030  
TR MA DE Rev003

ASV Stübbe GmbH & Co. KG  
Hollwieser Straße 5  
32602 Vlotho  
Germany  
Phone: +49 (0) 5733-799-0  
Fax: +49 (0) 5733-799-5000  
E-mail: [contact@asv-stuebbe.de](mailto:contact@asv-stuebbe.de)  
Internet: [www.asv-stuebbe.com](http://www.asv-stuebbe.com)



We reserve the right to make technical changes.  
Read carefully before use.  
Save for future use.

# Table of contents

<b>1 About this document</b>	4	<b>7 Menus and functions (not for C2)</b>	16
1.1 Target groups	4	7.1 Measured value display	16
1.2 Other applicable documents	4	7.2 Main menu	16
1.3 Warnings and symbols	5	7.3 Basic settings menu	16
<b>2 General safety instructions</b>	5	7.4 Output menu	17
2.1 Intended use	5	7.4.1 Output menu (relay)	17
2.2 General safety instructions	5	7.4.2 Output menu (current)	18
2.2.1 Obligations of the operating company	5	7.5 Display menu	18
2.2.2 Obligations of personnel	5	7.6 Diagnostics menu	18
2.3 Specific hazards	5	7.7 Service menu	19
2.3.1 Hazardous media	5	<b>8 Maintenance</b>	20
<b>3 Layout and Function</b>	6	8.1 Servicing	20
3.1 Name plate	6	8.2 Maintenance	20
3.2 Description	6	8.2.1 Removing the device	20
3.3 Layout	7	8.2.2 Replacement parts and return	20
3.3.1 UFM 600	7	<b>9 Troubleshooting</b>	21
3.3.2 UFM 600 Flex	7	9.1 Troubleshooting	22
3.3.3 UFM 200 Flex	7	9.1.1 Fixingsoftware loading errors	22
3.3.4 UNI display (optional, not possible for C2)	8	<b>10 Appendix</b>	23
3.3.5 Measured value display	8	10.1 Technical specifications	23
<b>4 Transport, Storage and Disposal</b>	9	10.2 Dimensions	23
4.1 Unpacking and inspection on delivery	9	10.3 Accessories	23
4.2 Transportation	9	10.4 Connection diagrams	23
4.3 Storage	9	10.4.1 Relay process connection	23
4.4 Disposal	9	10.4.2 Current connection diagram	24
<b>5 Installation and connection</b>	10	10.4.3 Current process connection (C2), 2-wire technology	24
5.1 Check operating conditions	10	10.4.4 Flex sensor connection	25
5.2 Install device	10		
5.2.1 Installing device in the tank	10		
5.2.2 Install device over the channel	10		
5.3 Electrical connection of device	11		
<b>6 Operation</b>	12		
6.1 Basic operation using the UNI display	12		
6.1.1 Measured value display	12		
6.1.2 Parameterizing	12		
6.2 Initial start-up	13		
6.2.1 Initial start-up with UNI display	13		
6.2.2 Initial start-up without UNI display	13		
6.2.3 UFM 600 C2 initial start-up	14		
6.2.4 UFM 200 C2 initial start-up	14		
6.3 Managing several devices (not for C2)	14		
6.3.1 Backing up parameter sets	14		
6.3.2 Parameterizing several devices	14		
6.4 Reading the data logger	14		
6.5 Updating firmware	15		

## List of figures

Fig. 1	Name plate .....	6
Fig. 2	Housing and sensor layout .....	7
Fig. 3	Housing and flex sensor layout .....	7
Fig. 4	Housing and flex sensor layout .....	7
Fig. 5	UNI display layout .....	8
Fig. 6	Display of measured values .....	8
Fig. 7	UNI display .....	12
Fig. 8	Adjusting potentiometers .....	13
Fig. 9	Set container depth .....	14
Fig. 10	Relay connection plan .....	23
Fig. 11	Current connection diagram .....	24
Fig. 12	UFM 600 sensor connection plan .....	24
Fig. 13	UFM 200 connector connection plan .....	24
Fig. 14	UFM 600 Flex connection plan .....	25
Fig. 15	UFM 200 Flex connection plan .....	25

## List of tables

Tab. 1	Other application documents, purpose and where found .....	4
Tab. 2	Warnings and symbols .....	5
Tab. 3	Button functions with measured value display .....	12
Tab. 4	Button functions when parameterizing .....	12
Tab. 5	Button function with measured value display .....	16
Tab. 6	Main menu .....	16
Tab. 7	Basic settings menu .....	17
Tab. 8	Output menu (relay) .....	17
Tab. 9	Output menu .....	17
Tab. 10	Output menu (current) .....	18
Tab. 11	Display menu .....	18
Tab. 12	Diagnostics menu .....	18
Tab. 13	Data logger settings .....	18
Tab. 14	Service menu .....	19
Tab. 15	Servicing activities .....	20
Tab. 16	Troubleshooting .....	21
Tab. 17	Accessories .....	23
Tab. 18	Relay terminal allocation .....	23
Tab. 19	Current terminal allocation .....	24
Tab. 20	Sensor terminal allocation .....	24
Tab. 21	Connector cable assignment .....	24
Tab. 22	UFM 600 Flex cable assignment .....	25
Tab. 23	UFM 200 Flex cable assignment .....	25

# 1 About this document

This manual

- is part of the equipment
- applies to all series referred to
- describes safe and proper operation during all operating phases

## 1.1 Target groups

### Operating company

- Responsibilities:
  - Always keep this manual accessible where the device is used on the system.
  - Ensure that employees read and observe this document, particularly the safety instructions and warnings, and the documents which also apply.
  - Observe any additional country-specific rules and regulations that relate to the system.

### Qualified personnel, fitter

- Mechanics qualification:
  - Qualified employees with additional training for fitting the respective pipework.
- Electrical qualification:
  - Qualified electrician
- Transport qualification:
  - Qualified transport specialist
- Responsibility:
  - Read, observe and follow this manual and the other applicable documents, especially all safety instructions and warnings.

## 1.2 Other applicable documents

To download:

### Resistance lists

Resistance of materials used to chemicals



[www.asv-stuebbe.de/pdf\\_resistance/300051.pdf](http://www.asv-stuebbe.de/pdf_resistance/300051.pdf)



To download:

### Data sheet UFM

Technical specifications, conditions of operation

[www.asv-stuebbe.de/pdf\\_datasheets/300184.pdf](http://www.asv-stuebbe.de/pdf_datasheets/300184.pdf)

To download:

### Data sheet UFM C2

Technical specifications, conditions of operation



[www.asv-stuebbe.de/pdf\\_datasheets/301194.pdf](http://www.asv-stuebbe.de/pdf_datasheets/301194.pdf)



To download:







### CE declaration of conformity

Conformity with standards

[www.asv-stuebbe.de/pdf\\_DOC/300150.pdf](http://www.asv-stuebbe.de/pdf_DOC/300150.pdf)


Tab. 1 Other application documents, purpose and where found

## 1.3 Warnings and symbols

Symbol	Meaning
 <b>DANGER</b>	<ul style="list-style-type: none"> <li>Immediate acute risk</li> <li>Death, serious bodily harm</li> </ul>
 <b>WARNING</b>	<ul style="list-style-type: none"> <li>Potentially acute risk</li> <li>Death, serious bodily harm</li> </ul>
 <b>CAUTION</b>	<ul style="list-style-type: none"> <li>Potentially hazardous situation</li> <li>Minor injury</li> </ul>
<b>NOTE</b>	<ul style="list-style-type: none"> <li>Potentially hazardous situation</li> <li>Material damage</li> </ul>
	<p>Safety warning sign</p> <ul style="list-style-type: none"> <li>Take note of all information highlighted by the safety warning sign and follow the instructions to avoid injury or death.</li> </ul>
	Instruction
1. , 2. , ...	Multiple-step instructions
✓	Precondition
→	Cross reference
	Information, notes

Tab. 2 Warnings and symbols

# 2 General safety instructions


 The manufacturer accepts no liability for damages caused by disregarding any of the documentation.

## 2.1 Intended use

The device measures or monitors the filling level of fluids via an ultrasonic sensor. The relay version switches off a consuming unit (e.g. pump) if limit values are exceeded or not achieved. The limit values are adjustable.

- Device must only be used for monitoring filling level in liquid media.
- Only use the device with suitable media (→ resistance lists).
- Adhere to the operating limits (→ [10.1 Technical specifications, Page 23](#)).

## 2.2 General safety instructions

 Observe the following regulations before carrying out any work.

### 2.2.1 Obligations of the operating company

#### Safety-conscious operation

- Only operate the device if it is in perfect technical condition and only use it as intended, staying aware of safety and risks, and in adherence to the instructions in this manual.
- Ensure that the following safety aspects are observed and monitored:
  - Intended use
  - Statutory or other safety and accident-prevention regulations
  - Safety regulations governing the handling of hazardous substances
  - Applicable standards and guidelines in the country where the pump is operated
- Make personal protective equipment available.

#### Qualified personnel

- Make sure all personnel tasked with work on the device have read and understood this manual and all other applicable documents, especially the safety, maintenance and repair information, before they start any work.
- Organize responsibilities, areas of competence and the supervision of personnel.
- The following work should be carried out by specialist technicians only:
  - Installation, repair and maintenance work
  - Work on the electrical system
- Make sure that trainee personnel only work on the device under supervision of specialist technicians.

### 2.2.2 Obligations of personnel

Only complete work on the device if the following requirements are met:

- System is empty
- System has been flushed
- System is depressurized
- System has cooled down
- System is secured against being switched back on again
- Do not make any modifications to the device.

## 2.3 Specific hazards

### 2.3.1 Hazardous media

- When handling hazardous media, observe the safety regulations for the handling of hazardous substances.
- Use personal protective equipment when carrying out any work on the device.
- Collect leaking pumped liquid and residues in a safe manner and dispose of in accordance with environmental regulations.

## 3 Layout and Function

### 3.1 Name plate




Fig. 1 Name plate

- 1 Device type
- 2 Filling level measurement range
- 3 Outlet
- 4 Connection (nominal width)
- 5 Media connection and gasket material
- 6 Installation type
- 7 ID number

#### Device types

- UFM R – Compact, relay output
- UFM Flex R – Flex, relay output
- UFM C4 – Compact, current output, 4-wire design
- UFM C4 – Flex – Flex, current output, 4-wire design
- UFM C2 – Compact, current output, 2-wire design

### 3.2 Description

The device measures or monitors the filling level of fluids via an ultrasonic sensor. The relay version switches off a consuming unit (e.g. pump) if limit values are exceeded or not achieved. The limit values are adjustable.

The device is suitable for measuring the filling level in pressureless tanks and pressure tanks. Underpressure, vacuum, or outgassing media increase the measurement inaccuracy.

The device is integrated within the control of the consuming unit using the following inputs and outputs:

- Relay version (R)
  - 4 relay outputs
- 4-wire current version (C4)
  - 1 current output (0/4–20 mA)
- 2-wire current version (C2)
  - 1 current output (4–20 mA)

#### Versions available:

- Compact
  - Compact housing
  - Process connection directly under the connection housing
- Flex
  - Connection and sensor housing separate
  - Process connection linked to the connection housing via cable
  - Sensor housing installed from above into a tank or container

The UNI display (optional, not possible for C2) shows measured value. It can be used for all measuring instruments of the UNI display device platform PTM, HFT and UFM. The UNI display offers the following additional functions:

- Graphic filling level display
- Displays status of the relay outputs
- Menu-guided device setting
- Data logger function with date stamp
- Saving and transfer of parameter settings to other sensors
- Memory function on microSD card
- Firmware update

### 3.3 Layout

#### 3.3.1 UFM 600



Fig. 2 Housing and sensor layout

- 1 Housing cover
- 2 Connection housing
- 3 Process connection
- 4 Sensor
- 5 Cable glands

#### 3.3.2 UFM 600 Flex




Fig. 3 Housing and flex sensor layout

- 1 Housing cover
- 2 Sensor housing
- 3 Process connection
- 4 Sensor
- 5 Spacer
- 6 Connection housing
- 7 Pipe clamp
- 8 Sensor cable

#### 3.3.3 UFM 200 Flex




Fig. 4 Housing and flex sensor layout

- 1 Plug connector cable
- 2 Fastening clamp
- 3 Sensor housing
- 4 Fastening clamp
- 5 Spacer
- 6 Connection housing
- 7 Pipe clamp
- 8 Sensor cable
- 9 Ground connection

### 3.3.4 UNI display (optional, not possible for C2)

The UNI display is fitted on to the connection housing (remove housing cover). The transparent cover supplied allows the measured values to be read during operation.

The device can be adjusted and put into operation using the UNI display.

The UNI display can be removed again once it has been put into operation. The UNI display remains attached if the intention is to display measured values permanently.




Fig. 5 UNI display layout

- 1 microSD card (with spring ejection)
- 2 Display
- 3 Battery
- 4 Operating buttons

### 3.3.5 Measured value display




Fig. 6 Display of measured values

- 1 Filling level display (absolute and as a percentage)
- 2 Relay status display (only for relay version)  
 Normal display = contact open  
 Inverted display = contact closed
- 3 Graphical filling level display
- 4 Measuring signal  
 no dot = no signal  
 one dot = good  
 two dots = very good



## 4 Transport, Storage and Disposal

### 4.1 Unpacking and inspection on delivery

1. Unpack the device when received and inspect it for transport damage and completeness.
2. Check that the information on the type plate agrees with the order/design data.
3. Report any transport damage to the manufacturer immediately.
4. If fitted immediately: Dispose of packaging material according to local regulations.
  - If fitted at a later point: leave device in its original packaging.

### 4.2 Transportation

- ▶ Device should preferably be transported in the original packaging.


### 4.3 Storage

#### NOTE

#### Material damage due to inappropriate storage!

- ▶ Store the device properly.
1. Make sure the storage room meets the following conditions:
    - Dry
    - Frost-free
    - Vibration-free
    - Not in direct sunlight
    - Storage temperature +10 °C to +60 °C
  2. Device should preferably be stored in the original packaging.

### 4.4 Disposal

-  Plastic parts can be contaminated by poisonous or radioactive media to such an extent that cleaning will not be sufficient.

#### WARNING

#### Risk of poisoning and environmental damage from medium.

- ▶ Use personal protective equipment when carrying out any work on the device.
  - ▶ Prior to the disposal of the device: Neutralize residues of medium in the device.
1. Remove battery and dispose of in accordance with local regulations.
  2. Remove electronic parts and dispose of in accordance with local regulations.
  3. Dispose of plastic parts in accordance with local regulations.

## 5 Installation and connection

### 5.1 Check operating conditions

1. Ensure the design of the fitting is consistent with the purpose intended:
  - Materials used ([→ 3.1 Name plate, Page 6](#)).
  - Medium ([→ order and design data](#)).
2. Ensure the required operating conditions are met:
  - Resistance of body and seal material to the medium ([→ resistance lists](#)).
  - No underpressure or vacuum in the tank.
  - Temperature and pressure ([→ 10.1 Technical specifications, Page 23](#)).
3. Consult with the manufacturer regarding any other use of the device.

### 5.2 Install device

#### 5.2.1 Installing device in the tank

- ✓ Carefully select installation location in the tank:
  - Perpendicular to the surface of the fluid
  - Observe minimum distance to maximum filling level ([→ 10.1 Technical specifications, Page 23](#)).
  - If tank is filled to the top edge, then provide a dome or set up a support to install the device
- ✓ Avoid interferences:
  - Do not install over turbulence or the vortex caused by agitators.
  - Do not install near filling pipes
  - Tank superstructures or installation (supports, dome, ladders, struts) must not protrude into the measuring cone of the device (aperture angle approx. 15°).
  - If necessary, shield tank installations (ladders, struts ...) with baffle plates (plastic or metal - no false echoes)
  - Install the device in a standpipe for heavily foaming media

---

#### NOTE

---

##### Damage to the device.

- Device must only be tightened to the tank using the correct wrench.

1. Ensure that the O-ring for sealing the process connection is inserted.
2. Screw sensor housing into the tank using the wrench (only hand-tight).

#### 5.2.2 Install device over the channel

- ✓ Select the installation location over the channel with care:
  - Perpendicular to the liquid
  - Observe minimum distance to maximum level ([→ 10.1 Technical specifications, Page 23](#)).
- ✓ Avoid interferences:
  - Do not install over turbulence or vortices
  - Do not install near inlet pipes

---

#### NOTE


---

##### Damage to the device.

- Device must only be tightened to the tank using the correct wrench.

1. Mount console as a bracket for the device above the channel.
2. Screw sensor housing into the console using the wrench (only hand-tight).

### 5.3 Electrical connection of device

- ✓ Device is installed.
  - ✓ Power supply is switched off and secured against being switched back on again.
-  Cable without shielding can be used to connect the device. If electromagnetic interference is anticipated, then use shielded cable.
- Terminal strips are pluggable.



#### **DANGER**

##### **Risk of electrocution**


- ▶ All electrical work must be carried out by qualified electricians only.
  - ▶ Switch off system power supply and secure it against being switched back on again.
- 
1. Unscrew the housing cover from the connection housing, remove UNI display if required.
  2. Guide the connection cable through the cable glands and connect:
    - Cable
    - Connection diagram ([→ 10.4 Connection diagrams, Page 23](#)).
  3. Tighten the cable glands securely.
  4. Screw on the housing cover.
  5. For the Flex version:
    - Cut connection cable to length.
    - Fit the plug ([→ 10.4 Connection diagrams, Page 23](#)).
    - Connect sensor housing and connection housing ([→ 10.4.4 Flex sensor connection, Page 25](#)).
  6. Connect ground connection with the equipotential bonding of the entire system ([→ Figure Housing and flex sensor layout, Page 7](#)).

## 6 Operation

### NOTE


**Changing parameters affects the switching outputs immediately.**

- Make sure that changing a parameter does not trigger a malfunction (e.g. a pump running dry).

 When switching on the device, all relay contacts are open for 3 s (NO).

After this the relay contacts assume the status which corresponds with the setting and the measured values.

### 6.1 Basic operation using the UNI display

 Description of menus and functions  
 (→ 7.2 Main menu, Page 16).




Fig. 7 UNI display

- 1 Display
- 2 Operating buttons

#### 6.1.1 Measured value display

The display shows the measured value.

Button	Function
<b>OK</b>	Main menu
<b>Esc</b>	Switches measured value display to time and date view.
<b>▲ ▼ simultaneously</b>	Changes the display direction.

Tab. 3 Button functions with measured value display

#### 6.1.2 Parameterizing

Button	Functions
<b>Esc</b>	<ul style="list-style-type: none"> <li>• Cancels input and switches to the higher-level menu.</li> <li>• Changes will not be saved.</li> </ul>
<b>▲</b>	<ul style="list-style-type: none"> <li>• Increases parameter value.</li> <li>• Previous menu/submenu</li> <li>• Press and hold to increase parameter value quickly.</li> <li>• Press ▼ at the same time to increase parameter value very quickly.</li> </ul>
<b>▼</b>	<ul style="list-style-type: none"> <li>• Reduces parameter value.</li> <li>• Previous menu/submenu.</li> <li>• Press and hold to reduce parameter value quickly.</li> <li>• Press ▲ at the same time to reduce parameter value very quickly.</li> </ul>
<b>OK</b>	<ul style="list-style-type: none"> <li>• Switches to the menu overview.</li> <li>• Switches to the menu/submenu selected.</li> <li>• Confirms parameter and saves value.</li> </ul>
If no button is pressed	<ul style="list-style-type: none"> <li>• The measured values are displayed after 2 minutes.</li> <li>• Changes will not be saved.</li> </ul>

Tab. 4 Button functions when parameterizing

## 6.2 Initial start-up

- i** Relay version: the UNI display is used for start-up.
- Current version, 4-wire: start-up can be completed without the UNI display. The response of the current outputs is adjusted via 2 potentiometers. Start-up is easier and quicker using the UNI display.
- Current version, 2-wire: can be started up without the UNI display. The container depth is set via a step switch.

### 6.2.1 Initial start-up with UNI display

- i** The UNI display can be removed again once it has been put into operation.
- The UNI display remains attached if the intention is to display measured values permanently.
- If the display is upside down, press ▲ ▼ buttons simultaneously.
- ✓ Device is installed properly.
  - ✓ Device is connected properly with the power supply and ready for operation.
1. Unscrew the housing cover.
  2. Insert UNI display on to the electronic equipment (white plug-in location).
  3. Configure device (→ 7.2 Main menu, Page 16).
  4. Remove UNI display if necessary.
  5. Screw on housing cover or transparent cover.

### 6.2.2 Initial start-up without UNI display

- ✓ Device is installed properly.
  - ✓ Device is connected properly with the power supply and ready for operation.
- i** For this purpose, the current output for filling level must be displayed in the higher-level controller as a measured value.




Fig. 8 Adjusting potentiometers

1. Unscrew the housing cover.
2. Fill tank to minimum depth.
3. Adjust current output for minimum filling level, at potentiometer R6:
  - Slowly turn the potentiometer to the right until the desired measured value for this filling level is read out.
4. Fill tank to maximum level.
5. Adjust current output for maximum filling level, at potentiometer R7:
  - Slowly turn the potentiometer to the right until the desired measured value for this filling level is read out.
6. Screw on the housing cover.

### 6.2.3 UFM 600 C2 initial start-up

- ✓ Device is installed properly.
- ✓ Device is connected properly with the power supply and ready for operation.





Fig. 9 Set container depth


1. Unscrew the housing cover.
2. Set container depth via the step switch:
  - 1 = 1 m corresponds to 20 mA
  - 2 = 2 m corresponds to 20 mA
  - 3 = 3 m corresponds to 20 mA
  - 4 = 4 m corresponds to 20 mA
  - 5 = 5 m corresponds to 20 mA
  - 6 = 6 m corresponds to 20 mA
3. Screw on the housing cover.

### 6.2.4 UFM 200 C2 initial start-up

- ✓ Device is installed properly.
- ✓ Device is connected properly with the power supply and ready for operation.
- No start-up necessary, the device is ready for operation.

## 6.3 Managing several devices (not for C2)

 Using the UNI display and microSD card, parameter sets can be transferred between devices or archived on a PC.

 All microSD cards or microSDHC cards with FAT32 formatting are supported. Files must be maintained in the master directory.

Files should be named in Format 8.3 (e.g. PARA\_1.ASV), otherwise only an abbreviated file name is displayed.

The memory function always names the files STUEBBE.ASV. If a STUEBBE.ASV file already exists on the microSD card, then this file is overwritten.


### 6.3.1 Backing up parameter sets

1. Save the parameter set from the device on to the microSD card (→ 7.7 Service menu, Page 19).
2. Insert the microSD card into the PC, then transfer and archive the STUEBBE.ASV file.

### 6.3.2 Parameterizing several devices


1. Parameterize the first device (→ 7.2 Main menu, Page 16).
2. Save the parameter set from the device on to the microSD card (→ 7.7 Service menu, Page 19).
3. Attach the UNI display, with the microSD cards inserted, on to the next device.
4. Save the parameter set from the microSD card on to the device (→ 7.7 Service menu, Page 19).

## 6.4 Reading the data logger

 Series of measurements can be created and read using the UNI display and microSD card.

1. Insert the microSD card in a UNI display and attach the UNI display to the device.
2. Set up the data logger function (→ 7.6 Diagnostics menu, Page 18).
3. Remove the microSD card and read the log file (csv format) on the PC.

## 6.5 Updating firmware

 Current sensor firmware or UNI display firmware can be obtained via the Internet  
(→ [www.asv-stuebbe.com/service/downloads](http://www.asv-stuebbe.com/service/downloads)).



In the event that the updating is interrupted  
(→ [9.1.1 Fixing software loading errors, Page 22](#)).

1. Download the latest version of the sensor firmware (e. g. UFM\_Vxxx..HEX for Compact version, UFR\_Vxxx.HEX for Flex version) and UNI display firmware (UNI\_Vxxx.HEX) from the Internet and save on the microSD card.
2. Insert the microSD card in a UNI display and attach the UNI display to the device.
3. Save sensor firmware or UNI display firmware from the microSD card on to the device (→ [7.7 Service menu, Page 19](#)).
4. Observe release notes. If “reset factory settings” is necessary:
  - Note all parameters.
  - Perform “reset factory settings” (→ [7.2 Main menu, Page 16](#)).
  - Reset the device (→ [7.7 Service menu, Page 19](#)).
5. Check date and time, and reset if necessary (→ [7.3 Basic settings menu, Page 16](#)).

## 7 Menus and functions (not for C2)

### 7.1 Measured value display

The display shows the measured value.

Button	Function
<b>OK</b>	Main menu
<b>Esc</b>	Switches measured value display to time and date view.
<b>▲ ▼</b> simultaneously	Changes the display direction.

Tab. 5 Button function with measured value display

### 7.2 Main menu

Main menu	Function
Basic settings	Performs basic settings (→ 7.3 Basic settings menu, Page 16).
Outlet	Adjusts the behavior of the outputs (→ 7.4 Output menu, Page 17).
Display	Sets the display options (→ 7.5 Display menu, Page 18).
Diagnostics	Checks the diagnostics functions (→ 7.6 Diagnostics menu, Page 18).
Service	Performs the service functions (→ 7.7 Service menu, Page 19).

Tab. 6 Main menu

### 7.3 Basic settings menu

Submenu values	Function
<b>Language</b>	
Deutsch English Français Español Italiano	Sets the operating language
<b>Lighting</b>	
Automatic	The display lighting switches on automatically for 15 seconds: <ul style="list-style-type: none"> <li>if the display value changes by 5 %</li> </ul>
using any button	The display lighting switches on for 15 s each time a button is pressed.
off	Display lighting is always off.
on	Display lighting is always on.
<b>Integration time</b>	
0 ... 60 s	Sets measurement interval for ultrasonic sensor to compensate for height fluctuations. An average is calculated and displayed using the measurement interval. This removes the effect of short-term height fluctuations. A long integration time delays the reaction to height fluctuations.
<b>Basic calibration</b>	
min. filling height	Setting % display filling height. The value set is displayed as "0 %": <ul style="list-style-type: none"> <li>▶ ▲ ▼ – sets filling height for 0 %</li> <li>▶ OK – accepts setting</li> </ul>
max. filling height	Setting % display filling height. The value set is displayed as "100 %": <ul style="list-style-type: none"> <li>▶ ▲ ▼ – sets filling height for 100 %</li> <li>▶ OK – accepts setting</li> </ul>
<b>Tank volume</b>	
xx.y m <sup>3</sup> xxxxx l	<ul style="list-style-type: none"> <li>▶ ▲ ▼ – sets volume of tank to be measured</li> <li>▶ OK – accepts setting</li> </ul>
xxxx mm	<ul style="list-style-type: none"> <li>▶ ▲ ▼ – sets height of tank to be measured</li> <li>▶ OK – accepts setting</li> </ul>
xxxx mm	<ul style="list-style-type: none"> <li>▶ ▲ ▼ – Sets installation height (height above tank floor) of the sensor.</li> <li>▶ OK – accepts setting</li> </ul>




Submenu values	Function
100%	► ▲▼ – tank height = 100 % (yes/no). ► OK – accepts setting
Container shape	
Linear Spherical tank Horizontal tank	► ▲▼ – sets tank shape. ► OK – accepts setting ► ▲▼ – sets number of tanks (1 ... 5) for accumulation tanks. ► OK – accepts setting
Sensor	
	Display of measurement range for the sensor installed.
Time	
DD.MM.YYYY HH:MM	Display/setting of date and time. The first position in the date is underlined. ► ▲▼ – adjusts value ► OK – accepts value and sets next position ► After setting minutes, OK returns you to the basic settings menu

Tab. 7 Basic settings menu

## 7.4 Output menu

### 7.4.1 Output menu (relay)

#### Selecting relay output

 The relay output is set first, and then the switch type. The switch behavior can then be set depending on the switch type selected. All 4 relay outputs are set in the same way.

Submenu values	Function
Relay 1 Relay 2 Relay 3 Relay 4	► ▲▼ – selects relay to be set  The set values are displayed.

Tab. 8 Output menu (relay)

#### Setting

Submenu values	Function
Switch type	
Distance Filling height Filling volume	Sets switch type: <ul style="list-style-type: none"> <li>Switches on / off with a change of ...</li> </ul>
Switching point 1	
	Sets switching point 1. In window mode, the value for switching point 1 must always be above the value for switching point 2.
Switch delay 1	
0 ... 60 s	Sets the switch delay for switching point 1. The switch delay is the period after which the relay switches once a switching point has been reached. The switch delay prevents, for example, the relay from rattling in hysteresis mode.
Switching point 2	
	As for switching point 1
Switch delay 2	
0 – 60 s	As for switch delay 1
Opener/Closer	
NO NC	Sets switch function: <ul style="list-style-type: none"> <li>NO – closer</li> <li>NC – opener</li> </ul> The relay outputs do not assume the switch function set here until approximately 3 seconds after switching on.
Mode	
Hysteresis Window	Sets mode: <ul style="list-style-type: none"> <li>Hysteresis               <ul style="list-style-type: none"> <li>Switches on when pressure/temperature increases at switch 1</li> <li>Switches off when pressure/temperature falls at switch 2</li> </ul> </li> <li>Window               <ul style="list-style-type: none"> <li>Switches on between switching point 1 and switching point 2</li> <li>Switches off under switching point 1 or over switching point 2</li> </ul> </li> </ul>

Tab. 9 Output menu

#### 7.4.2 Output menu (current)

Submenu values	Function
min. current	► ▲▼ – sets the value which should be read out at the current output with 0 (4) mA.
max. current	► ▲▼ – sets the value which should be read out at the current output with 20mA.
Adjustment by ...	
Potentiometer	Adjustment without UNI display via potentiometers.
Display	Adjustment via the UNI display. If the setting has been selected, the device can no longer be adjusted via the potentiometer.
Reference	► ▲▼ – sets the reference value for the current output.  Adjustable values: <ul style="list-style-type: none"> <li>• Distance</li> <li>• Filling height</li> <li>• Volume</li> </ul>


Tab. 10 Output menu (current)

### 7.5 Display menu

Submenu values	Function
Distance Filling height Volume	Setting the reference value and unit for the filling level display: ► ▲▼ – selects the reference value. ► Press OK; this will open the selection submenu for the respective unit. ► ▲▼ – selects the unit. ► OK – accepts setting

Tab. 11 Display menu

### 7.6 Diagnostics menu

 The data logger functions requires a microSD card. The data logger function saves the data in CSV format on the microSD card.

After the adjustable recording duration (per file) has expired, a new file is written until the microSD card is full or the data logger function is deactivated.

Submenu values	Function
Slave pointer	
Distance / height / volume	Displays minimum and maximum measured values for filling level
	Resets slave point via Service – Reset – Slave pointer
Status	
Sensor OK	No error message, device functions normally.
Exxx	Error message (→ <a href="#">Table 16 Troubleshooting, Page 21</a> ).
Data logger	
off	Data logger function switched off.
Hour, day, month, year	Sets the recording duration for the data logger function. Measurement interval and file name correspond to the following table.

Tab. 12 Diagnostics menu

Recording duration (per file)	Measurement interval	File name
Hour	5 s	monthdayhour.csv e.g 061814.csv
Day	2 min	yearmonthday e.g 20140618.csv
Month	1 h	yearmonth.csv e.g 201406.csv
Year	1.8 h	year.csv e.g 2014.csv

Tab. 13 Data logger settings

## 7.7 Service menu

- i** The UNI display supports all microSD or microSDHC cards with FAT32 formatting. Relevant file must be maintained in the master directory.
- If transmission errors occur when loading a parameter set, then the UNI display will restore its factory settings.
- The UNI display only displays files in 8.3 format.

Submenu values	Function
Reset	
Factory settings	Resets all parameters to the delivery state: ► OK – Delivery state is set.
Slave pointer	Resets slave pointer for filling level.
Info	
	Displays version of sensor firmware and UNI display firmware.
Memory	
to intermediate memory	Saves all parameters from the device on to the intermediate memory.
from intermediate memory	Saves all parameters from the intermediate memory on to the device.
to microSD card	Saves all parameters from the device on to the microSD card.
from the microSD card	Saves all parameters from the microSD card on to the device.
Update firmware	
firmware update for device	Load sensor firmware from the microSD card: ► Press and hold OK until "Bootloader" is displayed. ► Press OK - to list the existing files on the microSD card. ► ▲▼ – Select file (e. g. UFM_Vxxx.HEX for Compact version, UFR_Vxxx.HEX for Flex version) ► OK – the new firmware is loaded into the device and immediately started.
UniDisplay	Load UNI display firmware from the microSD card: ► Press and hold OK + Esc until "UNIBOOT" is displayed. ► Press OK - to list the existing files on the microSD card. ► ▲▼ – Selects file (UNI_Vxxx.HEX). ► OK – the new firmware is loaded into the device and immediately started.

Tab. 14 Service menu

## 8 Maintenance

### DANGER

#### Risk of electrocution!

- All electrical work must be carried out by qualified electricians only.

### WARNING

#### Risk of injury and poisoning due to hazardous or hot media.

- Use personal protective equipment when carrying out any work on the device.
- Allow device to cool.
- Make sure the device is depressurized.
- Block the media supply to the device.
- Empty the pipe and safely collect the media. Dispose of it in accordance with environmental regulations.
- Switch off the power supply to the system.
- Secure power supply against being switched back on again.
- Provide warning of maintenance and repair work and set up warning signs.

### 8.1 Servicing

Interval	Action
As necessary	<ul style="list-style-type: none"> <li>• Clean device with a damp cloth.</li> </ul>
Six-monthly	Visual and function check: <ul style="list-style-type: none"> <li>• Normal operating conditions unchanged</li> <li>• No leaks</li> <li>• No unusual operating noises or vibrations</li> </ul>
Yearly	<ul style="list-style-type: none"> <li>• Replace UNI display battery.</li> </ul>

Tab. 15 Servicing activities

- Perform maintenance tasks according to the table.

### 8.2 Maintenance

#### 8.2.1 Removing the device

- ✓ System is empty.
  - ✓ System has been flushed.
  - ✓ System is depressurized.
  - ✓ System has cooled down.
  - ✓ System is secured against being switched back on again.
1. Unscrew the housing cover from the connection housing, remove UNI display if required.
  2. Disconnect connection cable.
  3. Screw on the housing cover.
  4. Disassemble device from the process pipework.
  5. Decontaminate device if required.

#### 8.2.2 Replacement parts and return

1. Have the following information ready to hand when ordering spare parts (→ [3.1 Name plate, Page 6](#)).
  - Device type
  - ID number
  - Nominal pressure and diameter
  - Connection and gasket material
2. Please complete and enclose the document of compliance for returns (→ [www.asv-stuebbe.com/service/downloads](http://www.asv-stuebbe.com/service/downloads)).



3. Only use spare parts from ASV Stübbe.

## 9 Troubleshooting

### WARNING

**Risk of injury and poisoning due to hazardous media liquids!**

- Use personal protective equipment when carrying out any work on the device.


Error	Possible cause	Corrective action
Medium is leaking out of the flange	Pre-tension of the O-ring too small	► Tighten sensor housing using wrench.
"Display Vx.yy UNI" displayed	Error occurred when updating firmware	► Reload firmware (→ 9.1.1 Fixingsoftware loading errors, Page 22).
"FAIL" displayed Signal diagnosis: E005 - No echo	Cable connection to the sensor defective (only with Flex version)	► Check sensor cable (→ 10.4 Connection diagrams, Page 23). ► Replace sensor cable.
	No echo Sensor incorrectly aligned Sensor defective	► Check the perpendicular alignment of the sensor and correct if necessary. ► Replace device (for Compact version). ► Replace sensor housing (for Flex version).
Display "< min. !" or "> max. !" Signal diagnosis: E005 - Lower limit range or E006 - Upper limit range	Calculation of fill height and volume not possible	► Check settings <sup>1)</sup> and correct if necessary (→ 7.3 Basic settings menu, Page 16).
Display remains dark	Faulty power supply	► Ensure power supply is present.
	Wrong version of UNI display firmware	► Reload firmware (→ 9.1.1 Fixingsoftware loading errors, Page 22).
Display is upside down	Wrong display direction	► Press ▲▼ buttons simultaneously to change display direction.


Tab. 16 Troubleshooting

1) Specific gravity of medium, volume expansion. Tank volume and container form

## 9.1 Troubleshooting

### 9.1.1 Fixing software loading errors

 If an error occurs when updating the sensor firmware or the UNI display firmware (e.g. power failure), it may not be possible to call up the "Update firmware" menu.


 The latest sensor firmware or UNI display firmware is available on the Internet  
(→ [www.asv-stuebbe.com/service/downloads](http://www.asv-stuebbe.com/service/downloads)).




1. Save latest sensor firmware (e. g. UFM\_Vxxx.HEX for Compact version, UFR\_Vxxx.HEX for Flex version) or UNI display firmware (UNI\_Vxxx.HEX) on a microSD card.
2. Disconnect device from the power supply.
3. Insert UNI display and microSD card with current firmware where necessary.
4. Press hold OK in order to load the sensor firmware.
5. Press hold OK and ESC in order to load the UNI display firmware.
6. Switch on power supply.
7. OK, ▲▼ – Selects file.
8. Press OK.  
The latest firmware is loaded.
9. Press "OK" again.  
The latest firmware is launched.
10. Set the device again (→ [7.2 Main menu, Page 16](#)).

## 10 Appendix

### 10.1 Technical specifications

 Technical data (→ Data sheet).

### 10.2 Dimensions

 Dimensions (→ Data sheet).

### 10.3 Accessories

Description	Ident. number
UNI display	144153
<ul style="list-style-type: none"> <li>Display and control unit</li> <li>with PA transparent cover for the connector head</li> <li>Languages: DE, EN, FR, ES, IT</li> </ul>	
Battery, CR1220, 3 V	144328
Memory card, microSD	144329

Tab. 17 Accessories

### 10.4 Connection diagrams

#### 10.4.1 Relay process connection




Fig. 10 Relay connection plan

Terminal	Connection
18 ... 30 V DC	Power supply (18 ... 30 V DC)
0 V DC	Power supply (–)
1NO	Relay 1 switch output
1COM	Relay 1 COM
2NO	Relay 2 switch output
3NO	Relay 3 switch output
4NO	Relay 4 switch output
2 – 4 COM	Relay 2 – 4 COM

Tab. 18 Relay terminal allocation

### 10.4.2 Current connection diagram




Fig. 11 Current connection diagram

Terminal	Connection
X3	
PWR: 18 ... 30 V DC	Power supply (18 ... 30 V DC)
PWR: 0 V DC	Power supply (-)
X1	
OUT1: 0 ... 20 mA	0/4 ... 20 mA
OUT1: 0 V DC	Earth
OUT2: 0 ... 20 mA	0/4 ... 20 mA
OUT2: 0 V DC	Earth

Tab. 19 Current terminal allocation

### 10.4.3 Current process connection (C2), 2-wire technology




Fig. 12 UFM 600 sensor connection plan

1 Container depth step switch

Terminal	Connection
X3	
PWR: 18 ... 30 V DC	+4–20 mA
PWR: 0 V DC	-4–20 mA

Tab. 20 Sensor terminal allocation




Fig. 13 UFM 200 connector connection plan

Pin	Connection
1	+4–20 mA
2	-4–20 mA

Tab. 21 Connector cable assignment



#### 10.4.4 Flex sensor connection




Fig. 14 UFM 600 Flex connection plan

Sensor		Angled socket connection head	
1	Bus (+)	1	Bus (+)
2	Bus (-)	2	Bus (-)
		3	+5 V DC
3	18–30 V DC	5	18–30 V DC
4	0 V DC	4	0 V DC

Tab. 22 UFM 600 Flex cable assignment




Fig. 15 UFM 200 Flex connection plan

Angled socket sensor		Angled socket connection head	
1	Bus (+)	1	Bus (+)
2	Bus (-)	2	Bus (-)
3	+5 V DC	3	+5 V DC
4	0 V DC	4	0 V DC
5	18–30 V DC	5	18–30 V DC

Tab. 23 UFM 200 Flex cable assignment

